

Wirefree Monitoring System

CTVM300AFR

AEI Security & Communications Ltd

160507-6



Pack Contents

- 1 x Wirefree Camera
- 1 x Camera PSU
- 1 x Monitor
- 1 x Monitor PSU
- Fixings & Manual

In the interests of product development, cosmetic appearance & colour may differ.

IMPORTANT NOTICES

This system is **NOT SUITABLE FOR EXTERNAL USE**. Exposure to moisture may damage this device, render it unsafe for use and invalidate the 1 year warranty.

ALWAYS SWITCH OFF this device prior to connecting to mains power and when not in use.



- 1) Power switch (ON/OFF)
- 2) Volume control
- 3) Channel selector (1,2,3,4)
- 4) Audio level meter



- 1) 13.5VDC Power
- 2) Mode selector (WIRE/WIRELESS)
- 3) Audio/Video input (WIRE mode only)
- 4) Audio/Video output
- 5) V-Hold picture control
- 6) Contrast picture control
- 7) Brightness picture control

SEE OVERLEAF FOR QUICK SET UP GUIDE

Quick Set Up Guide



STEP 1

Use the supplied fixing kit to mount the camera bracket to a wall. Slot the camera on to the bracket and tighten screw to hold



STEP 2

Connect the 7.5VDC PSU to the camera and a suitable mains outlet. *USE ONLY THE PSU LABELLED 'CAMERA'*



STEP 3

Select the desired operating channel if required. Where multiple cameras are used, you will need to select a different channel for each camera.



- 1) IR Night Vision LED's
- 2) Microphone
- 3) Focus Adjustment
- 4) Channel Selector
- 5) Antenna
- 6) 7.5VDC

WARNING

The supplied power supplies may get hot during extended periods of use. This is normal and is NOT a hazard. **DO NOT COVER** the power supply units.



STEP 5

Position the monitor in a suitable location on a flat stable surface.



STEP 6

Connect the monitor PSU to the monitor and ensure the mode switch is set to 'WIRELESS'.



STEP 7

Connect the monitor 13.5V PSU to a mains socket and switch ON.



STEP 8

Switch ON and press the channel 1 selector.

PICTURE QUALITY NOTICE:

If you experience picture quality issues with this system please try the following. In the event the problem cannot be solved, please contact the AEI Helpline on 0845 1667940 or visit <http://www.aei.eu>

SYMPTOM

Rolling/Unsteady Picture

Too Bright/Dark

Unclear/'Grey' Picture

Interference

Fuzzy/Out of focus

SOLUTION

Adjust the V-HOLD control on the rear of the monitor

Adjust the BRIGHTNESS control on the rear of the monitor

Adjust the CONTRAST control on the rear of the monitor

Change the channel setting on both the camera and monitor

Adjust the focus control by turning the lens on the camera



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice

AEI SECURITY & COMMUNICATIONS

CE 0197

LOW POWER WIRELESS A/V PRODUCT OPERATING ON 2.4GHz

A/V Channel 4 not licensed for use in the following countries: **F** (France), **E** (España)

Hereby, AEI Security & Communications Ltd., declares that this wireless A/V device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.